

Remove the "Remove Before Flight" before arming the Mission Controls in the boosters.  
 Breaking of then Break Wire closes the Aux channel of the Mission Controls in the boosters.  
 The Aux channels of the boosters will go open when the booster is dropped.

