



Mission Control (Drop 1,3,5)

Mission Control (Drop 2,4,6)

Remove Before Flight

Booster 1 Droppers

Booster 2 Droppers

Booster 3 Droppers

Booster 4 Droppers

Booster 5 Droppers

Booster 6 Droppers

Remove this "Remove Before Flight" before the one to power the Mission Control.
 Check for all six continuity LEDs lighted before flight.